

## Setup:

**Intercom**-all parts are in the larger of the two small shipping cases

1. Place single beltpacks at the Accountant, Data Entry, Controller, Specialist, Assistant Specialist, Video Tagger, and Referee positions.
2. Connect a headset to each of the seven units.
3. Run a 3-pin Intercom cable from CH 1 on the Telex power supply to the closest beltpack. Daisy chain the row of beltpacks using additional 3-pin Intercom cables. If necessary, run a second daisy chain from CH 2 on the Telex power supply. There are 4 short and 4 long 3-pin Intercom cables.



Use CH 1,  
CH 2, or  
both



The INTERCOM connections on the processor generally are not used with the Telex Intercom. They are wired together if you need to run a third daisy chain.

4. Plug the Telex power supply into the UPS.
5. Verify the operation of each position by pressing the <TALK> button on the beltpack (light will turn on). Have another person listen on another station. Adjust volume as necessary. Press <TALK> button again to turn off mic.

**Teardown:**

Intercom-all parts go in the larger of the two small shipping cases

1. Disconnect the headsets from each of the beltpacks. Align the microphone with the headband. Pack the headsets in plastic bags without wrapping the cords around the ear pieces. Place the headsets in the plastic bags in the cloth tray in the Intercom shipping case.
2. Disconnect the 3-pin Intercom cables from each of the beltpacks and the Telex power supply. Be careful with the Female connector on the right side on the back of the beltpacks. Squeeze the metal clip (which is part of the beltpack, not part of the cable) towards the cable and pull the cable out.



Squeeze this clip and pull cable – do not pull on the clip



The clip stays on the beltpack. Do NOT try to pull on it.

- The Male connector (in the center of the beltpack) is much easier to disconnect. Simply squeeze the pin (it is part of the cable), and pull.
3. Place the beltpacks in the compartments on cloth tray in the Intercom shipping case.
  4. The Telex power supply goes in first in the bottom of the Intercom shipping case. The 4 long 3-pin Intercom cables go next to the Telex power supply. Put the tray on top of the power supply and long cables. The 4 short 3-pin Intercom cables go next to the tray. The Telex power cord also goes in tray with the beltpacks. The foam pad goes on top of the tray.



7 Headsets

7 Beltpacks

Telex power cord